AVE

Vacuum Instructional Guide

Preparation

Ensure the area you plan to vacuum is free of any large objects or debris that could clog the brushroll or hose. Remove toys, papers, and other obstacles from the floor.

Plug In

Inspect the power cord to ensure it is not frayed or tangled. Locate a nearby electrical outlet and plug in the power cord.

Adjust Settings

If applicable, adjust any settings/knobs for the surface you wish to clean such as Carpet or Hardwood.

Vacuuming

After powering on, slowly push the vacuum forward. Pull it back toward you to complete a pass. Repeat overlapping passes until the area is cleaned.

Emptying the Dustbin

To empty the dustbin, follow the below instructions.

1. Turn off and unplug the vacuum cleaner.
2. Press dirt cup, release button, and pivot cup out.
3. Hold the dirt cup over trash receptacle, push the dirt cup door, and release lever to open dirt cup door.
4. Close dirt cup door and press firmly to secure at front.
5. Place bottom of dirty cup into vacuum body first. Pivot dirt cup into vacuum body and press firmly until it locks into place.

Storage

When you're finished using the vacuum, rewind the cord (If applicable) and return to the storage location.